



SPORTident Printout Set Quick Start

Before:

1. Charge Printer overnight and carry extra AA batteries or ability to plug in
2. Plug Printout Set Master into MCP printer
3. Wake printer by pressing red/white SI button

During:

Remember: If using pCards press card **flat to hole** of stations

1. CLEAR the SI-Card (Using station labeled "SI-Master" or "Clear")
2. CHECK the SI-Card
Beeps if cleared, no beep means SI-Card needs clearing
3. START punch the SI-Card to begin timing
4. Visit and punch SI-Card to CONTROLS
Advise participants: "No beep, no time! Be sure you hear the beep."
5. FINISH punch SI-Card to end timing

After:

1. Hold SI-Card to Printout Set Master
 - a. Wake printer if needed
 - b. Print once for organizer, repeat to print again for participant
 - c. Check for correct control station IDs
 - d. Note cumulative time and split times
- Optional same day:
Download Printout Set Master to computer for bulk download of all SI-Card data
- Optional real time:
Download SI-Card via USB Master for results (requires computer and software)

Maintenance:

1. Time synchronize clocks on control stations every few months
Blue "SI-Master" - Service/Off stick to sync mode, pair to stations with coupling stick
2. Check batteries in all stations every few months, including Masters
All Stations - Service/Off stick to view consumption

james@SPORTident.us | [FAQ at shop.SPORTident.us](http://shop.SPORTident.us) | 877-322-4670